

Setback Distances in feet
 Morrison County, Minnesota Table date: March 8, 2012

Map Unit Symbol	Drain Depth, feet			
	2	3	4	5
25	100	170	230	290
161	130	210	280	350
202	130	200	260	320
260	140	240	320	400
261	120	190	260	340
265	80	160	220	290
265	80	160	220	290
292	50	70	100	120
337	140	250	350	400
375	160	260	350	400
413	190	310	400	400
540	50	70	80	90
541	200	250	300	350
543	50	110	210	290
544	50	70	80	90
549	200	250	300	350
1934	50	70	80	90
1946	140	250	350	400
1973	130	200	270	330
1998	50	80	100	120
155B	170	270	360	400
158B	130	190	250	310
182A	140	240	320	400
182B	140	240	320	400
200B	60	90	110	130
204B	60	90	120	140
233A	60	90	110	130
233B	60	90	110	130
302B	140	250	350	400
328B	150	230	300	360
341A	140	260	340	390
341B	140	260	340	390
454B	150	240	310	380
458A	140	210	280	340
458B	140	220	280	340

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.

Setback Distances in feet
Morrison County, Minnesota Table date: March 8, 2012

623A	170	330	400	400
623B	170	300	400	400
7A	130	250	350	400
7B	130	250	350	400
928B	60	90	120	140

Notes: 1) These setback distances are only for the situation where a drainage system will be installed and the landowner wishes to avoid impacting the wetland hydrology. 2) These values assume the ponded water on the site is 0.25" or less. 3) The effective depth of the drain (ditch or tile) is the elevation difference between the ground surface at the approximate setback distance and the water surface in the drain, or the bottom of the drain if it typically has no standing water.